



Genie Universal

All DCT4Plus Unlock Guide


- 1) Update your Genie's SD card content with [Genie Client Online Update](#)
- 2) Update your Genie's device OS firmware to v0.0.0.142r (Latest OS firmware is loaded to SD card after SD card content updated)
- 3) Install "GeniePlus.exe"
- 4) Plug-in Genie's Device on USB and run "Geniep.exe" from Genie "Menu =>Programs=>Nokia"
- 5) Let your window automatically install the USB drivers.
- 6) After all installation you may start running the GeniePlus.exe from your PC.



- 7) Select the type of phone you intend to unlock with. If it is belong to ASIC11, you may select DCT4Plus and ASIC 11 on the bottom of the "Mode menu"
- 8) Click Power "ON" if your phone are not in "LOCAL MODE" or "TEST MODE"
- 9) Click "SCAN" to read the phone status



- 10) Click "Install" to begin the repair/unlock process. Phone will be fully unlock/repair!



- 11) Click "Manual" ONLY to unlock/repair phone if process failed.

Tips:

- 1) Make sure your cable is connection is good.
- 2) Usually DCT4 cable is contain 68k resistor on BSI to GND and 3.3k resistor on BSI. Accept 2630 cable which is using 68k resistor on BSI to GND and 10k/5.1k resistor on BSI
- 3) You may skip "Power" and start with SCAN =>INSTALL if your phone can be automatically powered ON with LOCAL/TEST Mode